

 **Taranakipine™**
Wood Lock

WEATHERBOARD & FASCIA



**NO MORE
MITRES**



CODEMARK™
AQ-260315-CMNZ

🕒 **SAVE TIME** 🗑️ **LESS WASTE** ✓ **BRANZ TESTED**

☰ **SMOOTH FINISH** ↶ **EASY INSTALL** ☂️ **WEATHERTIGHT**

 **Taranakipine™**

ENGINEERED TO PERFORM

www.woodlock.co.nz

TARANAKIPINE WOOD LOCK WEATHERBOARDS

YOU'LL NEED

Brad nailer, 20-30mm brad nails, PURBOND or Gorilla Glue, sander, primer

AS EASY AS...



Wood Lock and cavity fix is the best way to ensure watertight homes. On cavity fix, Wood Lock can be joined anywhere, on or off stud. If you are installing Wood Lock direct fix, the joints must be on the stud.

- Secure the weatherboard with brad nails
- Cut the next board to the right length



- Place PURBOND or Gorilla Glue into the joint. Ensure there is enough glue to get glue squeeze out when the joint is locked



- With a second person, lift the new board into place and hook it into the joint
- Press hard and place four evenly spaced brad nails to secure the joint
- Continue installing the weatherboard

When the glue has cured, remove excess glue with a chisel and lightly sand smooth. If sanding removes the primer, paint over with a quality primer.

Taranakipine™

ENGINEERED TO PERFORM

www.woodlock.co.nz